

Sixty Four

Label Strip Creation and Installation

You can finish up your SixtyFour installation by creating very professional looking label strips for the front panel of the SixtyFour



It will make operating the SixtyFour from the front panel a real delight and completely intuitive ! If you take a little time to do this, it will really be worth the effort !

Each of the 32 sources or 32 destination labels can be as many as 10 characters long (including spaces).

Tools Needed:

- 1.) Xacto Knife.
- 2.) Microsoft Excel(tm) spread sheet program.
- 3.) Laser or Ink-jet printer.
- 4.) Glue stick.

Label Creation:

- 1.) Open the Excel template "SixtyFour Labeller.xls".
- 2.) Type in your desired labels into the Source and Destination fields.
- 3.) Execute a Save-As with a new file name.
- 4.) Print out the labels on standard Laser or Ink-jet paper.

Label Preparation:

- 1.) Using a straight edge and an Xacto knife trim the 2 sides of the strips to just outside the black line.
- 2.) Carefully cut along the rows to separate all 8 strips.

Label Installation:

- 1.) Slide the 4 white plastic backing strips to the right out of the label holders.
- 2.) Locate the label strip for Sources 1 - 8.
- 3.) Apply 1/2" of glue to one end of a white backing strip.
- 4.) Place the Source 1 end of the label strip over the glue and press down.
- 5.) Apply 1/2" of glue to the middle of the white backing strip just past the end of the Source 1 - 8 labels.
- 6.) Place the Source 9 end of the label strip over the glue and press down.
- 7.) Continue until all labels are applied.
- 8.) Position the Source 1 - 32 label strip at the right side of the top label holder.
- 9.) With your right hand, slowly slide the white backing strip to the left. Use your left hand guide the paper labels into the label holder.
- 10.) Continue until all the 32 sources and 32 destinations are labelled.

If you are using a Dashboard or MotorMate console to operate the SixtyFour remotely, we recommend also entering the same label characters into the SixtyFour's internal memory.



This is done from either console as described in their owners manuals. These labels will then appear on the Dashboard's or MotorMate's LCD display when you use the "ROUTER" section on those consoles.

